


Extention 5 Nkurenkuru:



Point	Latitude	Longitude
A	17°37'49.49"S	18°35'56.83"
B	17°37'24.65"S	18°35'48.57"E
C	17°37'3.01"S	18°36'28.47"E
D	17°37'33.29"S	18°36'38.71"E