

Zambezi Substation-Zambezi Earth Electrode Line, Station and Associated Infrastructure

Zambezi Substation - Zambezi Earth Electrode Line start Point:

Latitude :-17.501271 Longitude: 24.221832

Zambezi Earth Electrode Station Site:

Latitude: -17.718699 Longitude: 24.168731

